






TOP VIEW













BOTTOM VIEW


Compatible with MKR Boards




MKR BOARD












WARNING!


Advanced Section

The following information is for advanced use only and may not be officially supported by Arduino software






TOP VIEW



Disabling the LS/LDO pin it is possible to power the Nicla Sense ME using VDDIO_EXT pin on the header

If LS/LDO pin is enabled, it is possible to configure i) the Nicla Sense ME to work at +3V3 or +1V8, depending on the configuration of the maximum input voltage






TOP VIEW

Test Points

BOTTOM VIEW



TOP VIEW

